



## Accessoires



Code :	Type	Compatible avec :	Notes
PX GP-A	Gold Mount	Anton Bauer Gold Mount	For Replacing Mount Type
PX GP-S	V Mount	SONY V Mount	
PXS-GJS-T	Wireless	SONY V Mount Battery	Fixed On Camera Back
PXA-GJS-T	Receiver	Anton Bauer Gold Mount Battery	
PXWD-GJS-Z	Mount	Pro-X XP Type Li-ion Battery	Fixed On Battery Back
PX GP-TS	T Type	SONY V Mount Battery	Mounting Two Batteries For Shooting and Lighting Simultaneously
PX GP-TA	Mount	Anton Bauer Gold Mount Battery	

## Torches Caméra



Code :	Compatible avec :	Câble Long.	Température de couleur	Puissance	Options :
PX GP-L168	SONY SX Digital Camera	218mm	3200K	25W 12V	Filtre dichroïque 5600°K
PX BP-L168				25W/35W/50W 12V	
PX GP-L518	Cameras with Gold Mount	518mm		25W/35W/50W/75W /100W 12V	Diffuseur
PX BP-L518				25W/35W 12V	
PX NP-L168	All Cameras				