




Switch 3/3 rail 50

Switch for triple cyclorama Rail Type 50 system. To connect parking rails or feeding rails to the main curtain rail system. Closed loop curtain systems require switches for inserting or removing curtains for maintenance.

Reference: FF3755

EAN13: -



Switch for triple cyclorama Rail Type 50 system. To connect parking rails or feeding rails to the main curtain rail system. Closed loop curtain systems require switches for inserting or removing curtains for maintenance.

Caractéristiques :