

Switch 3/2 rail 50

Switch for double cyclorama Rail Type 50 system. To connect parking rails or feeding rails to the main curtain rail system. Closed loop curtain systems require switches for inserting or removing curtains for maintenance.

Reference: FF3756

EAN13: -



Switch for double cyclorama Rail Type 50 system. To connect parking rails or feeding rails to the main curtain rail system. Closed loop curtain systems require switches for inserting or removing curtains for maintenance.

Caractéristiques :