



## Switch 2/1 rail 50 DX

Switch for single cyclorama Rail Type 50 to connect parking rails or feeding rails to the main curtain rail. Closed loop curtain systems require switches for inserting or removing curtains for maintenance. (to order the left version use code FF3757SX).

Reference: FF3757

EAN13: -



Switch for single cyclorama Rail Type 50 to connect parking rails or feeding rails to the main curtain rail. Closed loop curtain systems require switches for inserting or removing curtains for maintenance. (to order the left version use code FF3757SX).

**Caractéristiques :**