
Adaptateur 7.2V pour caméra SONY DV

7.2V Adapter for SONY DV Camera

Reference: XP-DV-S

EAN13: -



Using brick battery to output 7.2V for SONY DV camera

Caractéristiques :

Application: Using brick battery to output 7.2V for SONY DV camera