

---

# Adaptateur 7.2V pour caméra Panasonic Lumix GH4

7.2V Adapter for Panasonic Lumix GH4 camera

Reference: XP-DV-GH4

EAN13: -



Using brick battery to output 7.2V for Panasonic Lumix GH4 camera

## **Caractéristiques :**

Application: Using brick battery to output 7.2V for Panasonic Lumix GH4 camera