

Kit alimentation pour caméra SONY EX1/EX3

Power supply set for SONY EX1/EX3 camera

Reference: XP-L70V-EX

EAN13: -



Using PRO-X XP-L70V battery to output 14.4V for SONY EX1/EX3 DV camera

Caractéristiques :

Application: Using PRO-X XP-L70V battery to output 14.4V for SONY EX1/EX3 DV camera